

# Setting Up Wi-Fi

## STEP 1

Insert the software CD into your CD-ROM drive. The scan tool selection menu will automatically appear:



*If the menu does not appear, click Start→Run, type D:\setup.exe (where 'D' is the drive letter of your CD-ROM drive), and click OK.*

Click on the icon labeled **OBdLink**.

## STEP 2

The OBdLink menu will appear:



Click on the **Setting up Wi-Fi and Bluetooth Options** link.

## STEP 3

The **Videos** menu will appear:



Click on the **OBdLink Wi-Fi Option** instructional video link for your operating system.

The video will start playing automatically. You can pause, stop and scroll through the video using the player controls.